CUKD-1 Sugar Grinder User Manual

Table of Contents

- 1. Introduction
- 2. Safety Instructions
- 3. Technical Specifications
- 4. Operating Instructions
- 5. Maintenance and Cleaning
- 6. Troubleshooting
- 7. Warranty and Support

1. Introduction

Thank you for purchasing the Königin CUKD-1 Sugar Grinder. This high-quality machine is designed to efficiently grind sugar into fine powder, perfect for beekeeping and other applications. Please read this manual thoroughly before using the machine to ensure safe and proper operation.

2. Safety Instructions

- Read all instructions before using the grinder.
- **Do not operate** the grinder if it has a damaged cord or plug.
- Unplug the grinder from the outlet when not in use and before cleaning.
- **Keep the grinder** out of reach of children.
- **Do not insert** fingers or objects into the grinder while it is operating.
- **Ensure all parts** are securely fastened before operation.

3. Technical Specifications

• Model: CUKD-1

Power Supply: 220V/50Hz
Power Consumption: 750W
Grinding Capacity: 150kg/h

• Weight:

• Dimensions:

4. Operating Instructions

1. **Ensure the grinder is properly assembled** and placed on a stable, flat surface.

- 2. **Place the desired equipment** under the grinder to collect the powdered sugar(Bag, barell etc.)
- 3. **Turn on the power switch** located on the side of the grinder.
- 4. **Feed sugar** into the hopper at the top of the grinder.
- 5. **Adjust the sugar flow** with the latch on the bottom of the funnel.
- 6. **Turn off the grinder** and unplug it when the grinding is complete.
- 7. Wait until the grinder stops and colelct the powdered sugar.

5. Maintenance and Cleaning

- Unplug the grinder before performing any maintenance or cleaning.
- Clean the funnel after each use with a dry cloth or brush.
- **Do not immerse** any parts of the grinder in water or other liquids.
- Regularly check the grinder for any signs of wear or damage.

6. Troubleshooting

- **Grinder does not start**: Ensure it is plugged in and the power switch is turned on.
- **Uneven grinding**: Check for blockages in the grinding chamber and ensure sugar is fed evenly.
- Excessive noise: Ensure all parts are securely fastened and check for foreign objects in the grinding chamber.

7. Warranty and Support

- This product comes with a **4-year warranty** covering manufacturing defects.
- For support or to report issues, please contact Königin customer service at:

o **Phone**: +36 30 609 6666

Email: info@konigin-trade.comWebsite: www.konigin-trade.com